



ATTACH THE WALL 1 TO THE CORNER POST OR WALL WITH #8 X 2" WOOD SCREW.

